



Teledex iPhone Cordless RediDock User Guide

Contacting Teledex

Worldwide Headquarters

6311 San Ignacio Ave.
San Jose, CA 95119

Telephone


Main: +1.408.363.3100
Toll Free (US) +1.800.794.8353
Fax: +1.408.363.3136

Internet

www.teledex.com

Email

sales@teledex.com



Introduction

Your Teledex iPhone RediDock handset and charging base is designed to be used with a full Teledex iPhone DECT cordless telephone. It will not function without a cordless base station with which to mate.

For operational instructions pertaining to the cordless handset, please refer to the user guide for the Teledex iPhone DECT cordless phone with which this RediDock is mated.

What's in Your Package

- Cordless Charging Base
- Cordless Handset
- AC Adapter
- Handset battery
- Battery compartment retaining screw and rubber screw cover

Battery Installation

1. Prepare to install the battery into the cordless handset by removing the battery cover and sliding it off. If the cover is secured with a screw, remove the screw first.
2. Insert the battery connector into the handset's connector. The connector is "keyed" so it only goes in one way. *Do not force the connection.*
3. Replace the battery compartment cover and the retaining screw.
4. Insert the rubber screw cover into the hole in which the screw is installed.
5. Place the handset on the charging base and ensure that the CHARGE LED lights, indicating the handset is receiving charging current. To obtain optimal performance of the telephone, be sure to charge the battery for 10 to 12 hours.

AC Adapter Installation

1. Place the AC adapter into an unswitched electrical outlet.
2. Plug the connecting cable from the AC adapter into the jack on the bottom of the phone. Route this cable through the cable channel out to the edge of the base.
3. Place the charging base in the desired location.

Base Registration Procedure

Before the cordless handset can begin to function, it must be "registered" with the corresponding base. To perform this registration process, place the cordless handset you wish to register onto the charging cradle of the base station of the main cordless phone. The handset will emit a beep when registration process is completed. The handset is now ready for use and may be placed on the RediDock charging base.

Wall Mounting Instructions

To mount your RediDock charging base on a wall, follow these steps:

1. Turn the base over and remove the wall mount stand by depressing the tab at the top of the stand and withdrawing the stand from the base.
2. Rotate the wall mount stand 180 degrees vertically and insert the two tabs on the stand into the matching holes in the middle of the base. Then snap the tab into the slot at the bottom of the base.
3. Remove the wall mount clip from the handset well. Rotate it 180 degrees vertically and reinsert it into its slot. This will help to retain the handset on the base when charging.

Technical Specifications

Dimensions

2.75" x 8.17"

Weight

With handset: 12 oz.

Without handset: 7 oz.

Power Adapter

9 VDC 300 mA adapter

Output rating at charger pin: 4.2V/18A

IMPORTANT SAFETY INSTRUCTIONS

WHEN USING YOUR TELEPHONE EQUIPMENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK AND INJURY TO PERSONS, INCLUDING THE FOLLOWING:

1. READ AND UNDERSTAND ALL INSTRUCTIONS.
2. FOLLOW ALL WARNINGS AND INSTRUCTIONS MARKED ON THE PRODUCT.
3. UNPLUG THE PRODUCT FROM THE WALL OUTLET BEFORE CLEANING. DO NOT USE LIQUID CLEANER OR AEROSOL CLEANERS.
USE A DAMP CLOTH FOR CLEANING.
4. DO NOT USE THIS PRODUCT NEAR WATER, FOR EXAMPLE, NEAR A BATHTUB, WASH BOWL, KITCHEN SINK OR LAUNDRY TUB, IN A WET BASEMENT, OR NEAR A SWIMMING POOL.
5. DO NOT PLACE THIS PRODUCT ON AN UNSTABLE CART, STAND OR TABLE. THE PRODUCT MAY FALL, CAUSING SERIOUS DAMAGE TO THE PRODUCT.
6. SLOTS AND OPENINGS IN THE CABINET AND THE BACK OF BOTTOM ARE PROVIDED FOR VENTILATION, TO PROTECT IT FROM OVERHEATING. THESE OPENINGS SHOULD NOT BE BLOCKED OR COVERED. THE OPENINGS SHOULD NEVER BE BLOCKED BY PLACING THE PRODUCT ON THE BED, SOFA, RUG OR ANY OTHER SIMILAR SURFACE. THIS PRODUCT SHOULD NEVER BE PLACED NEAR OR OVER A RADIATOR OR HEAT REGISTER. THIS PRODUCT SHOULD NOT BE PLACED IN A BUILT-IN INSTALLATION UNLESS PROPER VENTILATION IS PROVIDED.
7. NEVER PUSH OBJECTS OF ANY KIND INTO THIS PRODUCT THROUGH CABINET SLOTS AS THEY MAY TOUCH DANGEROUS VOLTAGE POINTS OR SHORT OUT PARTS THAT COULD RESULT IN A RISK OF FIRE OR ELECTRIC SHOCK. NEVER SPILL LIQUID OF ANY KIND ON THE PRODUCT.
8. TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT DISASSEMBLE THIS PRODUCT. BUT TAKE IT TO A QUALIFIED SERVICE FACILITY IF SERVICE OR REPAIR WORK IS REQUIRED. OPENING OR REMOVING COVERS MAY EXPOSE YOU TO DANGEROUS VOLTAGES OR OTHER RISKS. INCORRECT REASSEMBLY CAN CAUSE ELECTRIC SHOCK WHEN THE APPLIANCE IS SUBSEQUENTLY USED.
9. UNPLUG THIS PRODUCT FROM THE WALL OUTLET AND REFER SERVICING TO QUALIFIED SERVICE PERSONNEL UNDER THE FOLLOWING CONDITIONS:
 - WHEN THE POWER SUPPLY CORD OR PLUG IS DAMAGED OR FRAYED.
 - IF LIQUID HAS BEEN SPILLED INTO THE PRODUCT.
 - IF THE PRODUCT HAS BEEN EXPOSED TO RAIN OR WATER.
 - IF THE PRODUCT DOES NOT OPERATE NORMALLY BY FOLLOWING THE OPERATING INSTRUCTIONS. ADJUST ONLY THOSE CONTROLS THAT ARE COVERED BY THE OPERATING INSTRUCTIONS, AS IMPROPER ADJUSTMENT OF OTHER CONTROLS MAY RESULT IN DAMAGE, AND MAY REQUIRE EXTENSIVE WORK BY A QUALIFIED TECHNICIAN TO RESTORE THE PRODUCT TO NORMAL OPERATION.
 - IF THE PRODUCT HAS BEEN DROPPED OR THE CABINET HAS BEEN DAMAGED.
 - IF THE PRODUCT EXHIBIT A DISTINCT CHANGE IN PERFORMANCE.
10. AVOID USING A TELEPHONE (OTHER THAN A CORDLESS TYPE) DURING AN ELECTRICAL STORM. THERE MAY BE A REMOTE RISK OF ELECTRIC SHOCK FROM LIGHTNING.
11. DO NOT USE THE TELEPHONE TO REPORT A GAS LEAK IN THE VICINITY OF THE LEAK.

PLEASE SAVE THESE INSTRUCTIONS