
Quick User Guide

plantronics.

Plantronics CS510/CS520

Wireless Headset System



- 1 Decrease volume button (tap)
- 2 Answer/end call button (tap)
- 3 Mute button (tap base LED red)
- 4 Increase volume button (tap)

5 Narrowband/wideband audio switch

BlackNarrowband AudioYellowWideband Audio (deskphone must
be capable of wideband audio)

6 Auto answer switch

- Black (off) Tap call control button to place or answer call
- **Grey (on)** Lift headset from base to place or answer call

800.641.6416 or

CHAT ONLINE



Charging LED



NEED SUPPORT?